

Bano toilets and toilet seats

Care & maintenance instructions



BANO AS

Utstillingsplassen 3 6823 Sandane-Norway
Phone: +47 57 86 98 00
post@bano.no

Bano toilets and toilet seats

Products:

5885EC Bano easy clean toilet bowl 530 mm

5995EC Bano easy clean toilet bowl 700 mm

5970-06 Bano toilet seat - grey

5970-03 Bano toilet seat - white

5970-04 Bano toilet seat - black

5970-07 Bano toilet seat - red



Material specification

- Toilet 530 / 700 mm: glazed porcelain
- Toilet seat: ABS hygienic plastic
- Fittings: stainless steel

Maintenance

The product, which is made of porcelain, requires only minimum maintenance. Use a soft cloth or sponge with a mild cleaning agent. For a shining surface, use a detergent designed for cleaning windows.

Removing stubborn stains

You can often use stain remover to deal with stubborn stains from hard water or water that contains rust, but make sure to rinse the product thoroughly after cleaning. Regular cleaning will help to protect the surface of the product against marks and stains left by water. When needed, use a polishing agent to refresh the appearance of the porcelain surface.

Toilet seats in everyday use in the healthcare sector are exposed to a large load sideways when moving a patient from a wheelchair. The Bano toilet seat should always be fitted with the seat stabilizers bumpers to limit load sideways. Over time, however, the bolts in the seat can loosen gradually and we recommend tightening bolts 6 months after installation or when as needed.

Warning

Never use scouring agents or cleaning agents that contain strong chemicals. You must also make sure never to spill hot water or place very hot items on the surface. The highest safe temperature is 80 °C (the standard temperature of hot water from the tap is just 60 °C).

Thank you for taking the time to read these instructions carefully – it is a time well spent!